# INFINITY IYASHI QUICK START GUIDE

1. **MULTI FUNCTION SCREEN –** Menu options and massage status appear on this screen.
2. **POWER BUTTON – On/Off**
3. **MENU –** Return to the menu from any screen.
4. **SHOULDER POSITION ADJUSTMENT –** For adjustment of the position of the massage in manual and point mode.
5. **AUTO -** Select from six pre-set massage programs:

**RECOVERY** – Recover after a physically demanding day, with this strenuous and invigorating, full body massage.

**REFRESH** – Revive and revitalize your system with a gentle full body massage.

**EXTEND** - Gentle stretching and pulling loosens stiff muscles and joints, enhances flexibility.

**RELAX** – Rest and relax with a soothing moderate massage featuring air pressure massage for the neck and shoulders.

**UPPER AUTO -** Focus on key muscle groups in the upper body area.

**LOWER AUTO** – Focus on key muscle groups in the lower body area.

6. **DIRECTION BUTTON -**

In the menu, and in auto mode, click up, down, left, and right buttons to choose the function, then click "OK" to confirm.

7. **LEGREST UP AND DOWN –** Use these buttons to raise and lower the legrest.
8. **RECLINE CONTROL -** Use these buttons to recline and raise the seat back.
9. **ZERO GRAVITY-** Use this button to engage one of 2 Zero Gravity positions. This chair uses the NASA zero gravity principle, keeping the legs higher than the heart, imitating weightlessness. This position is known to increase comfort and release stress.
10. **LEGREST IN AND OUT-** Use these buttons to adjust the legrest out or in for comfort.

## INFINITY IYASHI MASSAGE CHAIR
## QUICK START GUIDE

Once your chair is plugged in and the power button on the rear lower panel is in the on position, you can begin using your massage chair. Start by pressing the power button on the upper left of your remote.

**Auto Programs** - You can choose one of the six auto programs by selecting the auto button on the remote. 1) **Recover** 2) **Refresh** 3) **Extend** 4) **Relax** 5) **Upper Auto** 6) **Lower Auto.** The programs take you through a fully automated massage each addressing your specific needs. The massage time can be adjusted by selecting the desired time in the menu under settings. Auto timer options are 10, 20, and 30 minutes.

**Custom Massage -** After pressing the power button then press the "**Menu**" button directly below the power button. From the menu select manual then mode then one of the six roller massages 1) Kneading 2) Tapping 3) Knocking 4) Shiatsu 5) Sync (tapping and knocking) 6) Rhythm (Sync to music coming in through Bluetooth).
While enjoying any custom massage, you can further customize by selecting the manual options available in the menu for "**Part**" and/or "**Width**" and/or "**Speed".**

To enjoy a foot massage, activate the foot rollers with the "**Rollers**" menu option. The three speeds can be changed in this menu.

Select "**Heat**" from the menu to activate the Lumbar Heat. Allow a few minutes for the heat benefits to be felt.

**Music** – Relax to your own music selection using a music compatible Bluetooth device. Using your bluetooth device, you can pair with the chair allowing it to stream your music through the stereo system built into Iyashi. Volume is controlled from the music device. Music selection is done from the music device.

INFINITY™

## INFINITY IYASHI MASSAGE CHAIR
# QUICK START GUIDE

INFINITY™

Infinite Therapeutics • 68 Route 125 Kingston, NH 03848 • (603) 347-6006